



TB87-3 PIR SENSOR



Detection Area



Daylight Sensor



Stand-by period





Hold Time




Technical Data

Operating Voltage 10.5-15V DC, Input Current >30mA	Sensitivity Setting 100%/75%/50%/25%	Peak Output Signal ≥ 3500mV
Operating Current <15mA	Hold Time 5s/30s/1min/3min/5min/10min/20min/30min	PIR Sensitivity 3200V/W
Connection 3Pin	Stand-by Period Os/10s/30s/1min/5min/10min/30min/60min/+∞	Mounting Height ≤12m
Warm-up Period 45±5s	Stand-by dimming level 10%/20%/30%/50%	Detection Range Radius: 4-8m/13.12-26.24ft
Control ON/OFF 0-10V	Daylight Threshold 2Lux/10Lux/30Lux/50Lux/80Lux/120Lux/Disable	Programming HD05R
Detection Angle With Fresnel Lens <120°	PIR Wave Length 5-14um	Operating Temperature


Daylight Priority

When it's programmed as standby dimming level 10% 20% or 30%, standby period as +∞ and dayligt threshold as 120Lux, 80Lux, 50Lux or 30Lux.











Dimensions Unit: mm







- 1. Please read the instructions carefully before using this product and keep it well for all users to read at any time.
- 2. The sensor should be installed by qualified electrician and ensure power is off before the installation.
- 3. We reserve the right to modify any incorrect text, image and necessary technical parameters.
- 4. Any unauthorized modification is forbidden, otherwise all guarantees will be immediately invalid.

Installation precautions

- 1. Turn the power off at the circuit breaker before installing the sensor.
- 2. Do not allow bare wires to show.
- 3. Assemble any necessary mounting accessories.
- 4. Have the sensor's lens lower than edge of the fixture and keep the sensor away from heating part.

Application Environment

- 1. Do not mount it outdoor, in case the outdoor temperature disturbs it.
- 2. Do not have it at places with suddenly changed temperature or airflow.
- 3. Do not have shelves between sensor to the presence area.